

PICA V

Service Instructions



Edition: 01/25

Copyright

Copyright by Carl Valentin GmbH

Subject to modifications.

All rights, including those regarding the translation, are reserved.

No part of this document may be reproduced in any form (print, photocopy, or any other method) or edited, copied, or distributed electronically without written permission from Carl Valentin GmbH.

Trademarks

All named brands or trademarks are registered brands or registered trademarks of their respective owners and may not be separately labelled. It must not be concluded from the missing labelling that it is not a registered brand or a registered trademark.

Carl Valentin uses Free and Open Source Software within its products. For more information see www.carl-valentin.de/opensource.

Topicality

Information on the scope of delivery, appearance, performance, dimensions, and weight reflect our knowledge at the time of printing.

Due to constant further development of our products discrepancies between documentation and product can occur.

Please check www.carl-valentin.de for the latest update.

Terms and Conditions

Deliveries and services are effected under the General Conditions of Business of Carl Valentin GmbH

Licences

- CE** Low-Voltage Directive (2014/35/EU)
 Electromagnetic Compatibility Directive (2014/30/EU)
 RoHS Directive (2011/65/EU)



Carl Valentin GmbH

Neckarstraße 78 – 86 u. 94
78056 Villingen-Schwenningen

Phone +49 7720 9712-0
E-Mail info@carl-valentin.de
Internet www.carl-valentin.de

Table of Contents

| | | |
|-----------|--|-----------|
| 1 | Notes on this Document | 5 |
| 1.1 | User Notes..... | 5 |
| 1.2 | Instructions | 5 |
| 1.3 | Cross References..... | 6 |
| 2 | Safety Instructions | 7 |
| 2.1 | General Safety Instructions | 7 |
| 2.2 | Safety Handling when Working with Electricity | 9 |
| 3 | Connector Pin Assignment (Printer Rear) | 11 |
| 4 | Cleaning | 13 |
| 4.1 | General Cleaning..... | 14 |
| 4.2 | Clean the Transfer Ribbon Drawing Roller | 14 |
| 4.3 | Clean the Pressure Roller | 15 |
| 4.4 | Clean the Printhead..... | 16 |
| 4.5 | Clean the Label Photocell | 17 |
| 5 | Replacing Components | 19 |
| 5.1 | Tool List..... | 19 |
| 5.2 | Replace the Printhead | 20 |
| 5.3 | Adjust the Print Position | 22 |
| 5.4 | Replace the Pressure Roller | 23 |
| 5.5 | Replace the Label Photocell..... | 24 |
| 5.6 | Replace the CPU PCB | 25 |
| 5.7 | Replace the Power Supply | 26 |
| 5.8 | Replace the Battery | 27 |
| 6 | Adjustments, Settings and Alignments | 29 |
| 6.1 | Adjust the Print Mechanism..... | 29 |
| 6.2 | Adjust the Printhead | 30 |
| 6.3 | Adjust the Transfer Ribbon Feed Path | 32 |
| 6.4 | Oil and Lubricate | 33 |
| 7 | Retrofit with Options | 35 |
| 7.1 | I/O Plate..... | 35 |
| 7.2 | Dispenser Unit..... | 36 |
| 7.3 | Cutting Unit..... | 37 |
| 8 | Error Correction..... | 39 |
| 9 | Control Inputs and Outputs..... | 49 |
| 10 | Wiring Plan..... | 57 |
| 10.1 | CPU Component Placement Specification..... | 58 |
| 11 | Environmentally-Friendly Disposal | 59 |
| 12 | Index | 61 |

1 Notes on this Document

1.1 User Notes

This service manual is intended for qualified service and maintenance staff.

This manual contains information about the electronics and the mechanical part of the printing system.

Information about operation of printer can be taken from our operating manual.

If a problem arises that cannot be solved with help of this service of manual, then please contact your responsible dealer.

1.2 Instructions

Basic information and warning references with the corresponding signal words for the danger level are as follows specified in this manual:



DANGER identifies an extraordinarily great and immediate danger which could lead to serious injury or even death.



WARNING identifies a possible danger could lead to serious bodily injury or even death if sufficient precautions are not taken.



WARNING of cutting injuries.

Pay attention that cutting injuries caused by blades, cutting devices or sharp-edged parts are avoided.



WARNING of hand injuries.

Pay attention that hand injuries caused by closing mechanical parts of a machine/equipment are avoided.



WARNING of hot surfaces.

Pay attention so as not to come into contact with hot surfaces.



CAUTION indicates a potentially dangerous situation which could lead to moderate or light bodily injury or damage to property.



NOTICE gives you tips. They make a working sequence easier or draw attention to important working processes.



Gives you tips on protecting the environment.



Handling instruction



Optional accessories, special fittings

Date

Information in the display

1.3 Cross References

Drawings

References to specific items in a figure are marked with letters. They are identified with parentheses in the text, e.g. (A). If no figure number is provided, letters in the text always refer to the graphic directly above the text. If a reference is made to another graphic, the figure number is specified, e.g. (A, in figure 5).

Cross references to chapters and sections

For a cross reference to chapters and sections, the chapter number and page number are specified, e.g. a reference to this section: see chapter 1.3.2, page 35).

References to other documents

References to other documents have the following form: See *'operating manual'*.

2 Safety Instructions

2.1 General Safety Instructions

Workplace and method of working

- ⇒ Keep the area around the device clean during and after maintenance.
- ⇒ Work in a safety-conscious manner.
- ⇒ Store dismantled device parts in a safe place while maintenance is being performed.

Clothing



WARNING!

The drawing in of items of clothing by moving parts can lead to injuries.

- ⇒ If possible, do not wear clothing which could be caught by moving device parts.
- ⇒ Button or roll up shirt or jacket sleeves.
- ⇒ Tie or pin up long hair.
- ⇒ Tuck the ends of scarves, ties and shawls into your clothing or secure them with non-conductive clips.



DANGER!

Risk of death from increased flow of current via metals parts which come into contact with the device.

- ⇒ Do not wear clothing with metal parts.
- ⇒ Do not wear jewellery.
- ⇒ Do not wear glasses with a metal frame.

Protective clothing

If a possible danger to your eyes is present, wear protective goggles, especially in the following cases:

- when knocking in or knocking out pins and similar parts with a hammer
- when using spring hooks
- when loosening or inserting springs, snap rings and gripping rings
- when soldering
- when using solvents, cleaning agents or other chemicals

Protective equipment**WARNING!**

Risk of injury in case of missing or faulty protective equipment.

- ⇒ After performing maintenance work, attach all safety equipment (covers, safety precautions, ground cables etc.).
- ⇒ Replace faulty parts and those which have become unusable.

2.2 Safety Handling when Working with Electricity

Qualifications of personnel

- ⇒ The following work may only be performed by instructed and trained electricians:

work on the electrical assemblies

work on the device while it is open and connected to the power supply.

General precautions to be heeded when beginning maintenance

- ⇒ Locate the emergency-stop or power switch so that it can be actuated in case of an emergency.

- ⇒ Unplug the device from the electrical outlet before performing the following work:

removing or installing power supply units

working in the immediate vicinity of exposed power supply parts

mechanical inspection of power supply parts

modifying the device circuits.

- ⇒ Ensure that the device is de-energized.

- ⇒ Check the workplace for possible sources of danger, e.g. moist floors, defective extension cables, faulty protective conduction connections.

Additional precautions to be heeded for devices with exposed energized parts

- ⇒ Give another person the task of remaining near the workplace. This person must be familiar with the location and operation of the emergency-stop and power switches and switch off the power if danger arises.

- ⇒ Use only one hand while working on electrical circuits when a device is switched on. Hold the other hand behind your back or put it in your jacket pocket.
This prevents the electricity from flowing through your body.

Tools

- ⇒ Do not use worn or damaged tools.

- ⇒ Use only tools and testing equipment that is suitable for the respective task.

What to do in case an accident occurs

- ⇒ Proceed in a very cautious and calm manner.
- ⇒ Avoid endangering yourself.
- ⇒ Switch the power off.
- ⇒ Request medical help (emergency physician).
- ⇒ Call for first aid if necessary.

3 Connector Pin Assignment (Printer Rear)




Figure 1

- A Switch On/Off
- B Plug-in for SD card
- C USB 2.0 Hi-Speed Device (for connection PC)
- D Ethernet 10/100 interface
- E Serial interface RS-232
- F Winder connection



CAUTION!

The label printer can be damaged by non-compliant winders.

⇒ Attach only winders of Carl Valentin.

- G External Output/Input (Option)
- H Power supply

4 Cleaning



DANGER!

Risk of death via electric shock!

⇒ Before opening the housing cover, disconnect the label printer from the mains supply and wait for a moment until the power supply unit has discharged.



CAUTION!

Risk of injury when cleaning.

⇒ Pay attention to sharp edges.



NOTICE!

When cleaning the label printer, personal protective equipment such as safety goggles and gloves are recommended.

Cleaning plan

| Cleaning task | Frequency |
|---|--|
| General cleaning (see chapter 4.1, on page 14). | As necessary. |
| Clean the transfer ribbon drawing roller (see section 4.2, page 4.2). | Each time the transfer ribbon is changed or when the printout is adversely affected. |
| Clean the print roller (see chapter 4.3, on page 15). | Each time the label roller is changed or when the printout and label transport are adversely affected. |
| Clean the printhead (see chapter 4.4, on page 16). | Direct thermal printing: Each time the label roller is changed. Thermal transfer printing: Each time the transfer ribbon is changed or when the printout is adversely affected. |
| Clean the label photocell (see chapter 4.5, on page 17). | When the label roller is changed. |



NOTICE!

The handling instructions for the use of Isopropanol (IPA) must be observed. In the case of skin or eye contact, immediately wash off the fluid thoroughly with running water. If the irritation persists, consult a doctor. Ensure good ventilation.

**WARNING!**

Risk of fire by easily inflammable label soluble!

- ⇒ When using label soluble, dust must be completely removed from the label printer and cleaned.

4.1 General Cleaning

**CAUTION!**

Abrasive cleaning agents can damage the label printer!

- ⇒ Do not use abrasives or solvents to clean the outer surface of the label printer.
- ⇒ Remove dust and paper fuzz in the printing area with a soft brush or vacuum cleaner.
- ⇒ Clean the outer surfaces with an all-purpose cleaner.

4.2 Clean the Transfer Ribbon Drawing Roller

A soiled drawing roller can lead to reduced print quality and can affect transport of material.

1. Open the printer cover.
2. Remove the transfer ribbon from the label printer.
3. Remove deposits with roller cleaner and a soft cloth.
4. If the roller appears damaged, replace it.

4.3 Clean the Pressure Roller

A soiled pressure roller can lead to reduced print quality and can affect transport of material.

**CAUTION!**

Pressure roller can be damaged!

⇒ Do not use sharp or hard objects to clean the pressure roller.




Figure 2

1. Open the printer cover.
2. Turn the lever (B) counter clockwise to lift up the printhead (A).
3. Remove labels and transfer ribbon from the label printer.
4. Remove deposits with the roller cleaner and a soft cloth.
5. Turn the roller (C + D) manually step by step to clean the complete roller (only possible when printer is switched off, as otherwise the step motor is full of power and the roller is kept in its position).
6. If the roller appears damaged, replace it (see chapter 5.3, on page 22).
7. Reload the labels and transfer ribbon.
8. To move the printhead (A) down, turn the pressure lever (B) in clockwise direction until it locks.
9. Close the printer cover.

4.4 Clean the Printhead



CAUTION!

Risk of injury from the hot printhead!

- ⇒ Make sure the printhead has cooled down before cleaning.

Printing can cause accumulation of dirt at printhead e.g. by colour particles of transfer ribbon, and therefore it is necessary to clean the printhead in regular periods depending on operating hours, environmental effects such as dust etc.



CAUTION!

Printhead can be damaged!

- ⇒ Do not use sharp or hard objects to clean the printhead.
- ⇒ Do not touch protective glass layer of the printhead.




Figure 3

1. Open the printer cover.
2. Turn the pressure lever (B, Figure 2) counter clockwise to lift up the printhead (A, Figure 2).
3. Remove the labels and transfer ribbon from the label printer.
4. Clean the printhead surface with a special cleaning pen or a cotton swab dipped in pure alcohol.
5. Before using the label printer, let the printhead dry for about two to three minutes.
6. Reload the labels and transfer ribbon.
7. To move the printhead (A, Figure 2) down, turn the pressure lever (B, Figure 2) in clockwise direction until it locks.
8. Close the printer cover.

4.5 Clean the Label Photocell



CAUTION!

Label photocell can be damaged!

⇒ Do not use sharp or hard objects or solvents to clean the label photocell.

The label photocell can be soiled with paper dust. This may affect the label scanning.




Figure 4

1. Open printer cover.
2. Turn the pressure lever (B, Figure 2) counter clockwise to lift up the printhead (A, Figure 2).
3. Remove labels and transfer ribbon from the label printer.
4. Blow out the photocell (A) with pressure gas spray. Observe strictly the instructions on the spray can!
5. Clean the label photocell (A) additionally with a cleaning card (B) before soaked in pure alcohol. Move the cleaning card from one side to the other (see illustration).
6. Reload the labels and transfer ribbon.
7. To move the printhead (A, Figure 2) down, turn the pressure lever (B, Figure 2) in clockwise direction until it locks.
8. Close the printer cover.

5 Replacing Components



DANGER!

Risk of death via electric shock!

⇒ Before opening the housing cover, disconnect the label printer from the mains supply and wait for a moment until the power supply unit has discharged.

5.1 Tool List

Some service work requires the following tools:

- Philips-head screwdriver, size 1
- Hexagonal wrench 1.5 mm
- Hexagonal wrench 2.5 mm
- Spring scale 10 N
- Spring scale 25 N

5.2 Replace the Printhead



CAUTION!

The printhead can be damaged by static electricity discharges and impacts!

- ⇒ Set up the printer on a grounded, conductive surface.
- ⇒ Ground your body, e.g. by wearing a grounded wristband.
- ⇒ Do not touch the contacts on the plug connections (B, C).
- ⇒ Do not touch the printing line (E) with hard objects or your hands.




Figure 5



NOTICE!

The printhead (D) is preinstalled on a head plate (A) and aligned at the factory.



CAUTION!

Danger of abrasion when removing/installing the printhead!

- ⇒ Pay attention to the toothing when the tear-off edge is installed.




Figure 6

Remove the printhead

1. Remove labels and transfer ribbon from the label printer.
2. When the printhead is closed, loosen the fixing screw (B).
3. Turn the pressure lever (D) counter clockwise to lift up the printhead.
4. If the printhead (E) is not disengaged on the pressure roller, continue loosen the fixing screw (B).
5. Remove the printhead carefully to the front until you can reach the plug connections.
6. Remove the plug connections and then remove the printhead (E).
7. Loosen the fixing screws (G) and remove the guiding (H).

Install the printhead

1. Mount the guiding (H) with the fixing screws (G) at the printhead.
2. Attach the plug connections.
3. Position the printhead in the printhead mounting bracket in such a way that the pins are secured in the corresponding holes in the head plate.
4. Lightly keep the printhead mounting bracket on the pressure roller with one finger and check for correct positioning of the printhead.
5. Screw in the fixing screw (B) and tighten it.
6. Reload the labels and transfer ribbon.
7. Check the resistance value on the type plate of printhead and if necessary change the value in the Service Functions/Heater Resistance.
8. Check the position of printout and if necessary adjust the print position (see chapter 5.3).

5.3 Adjust the Print Position

Zero point adjustment in Y direction




NOTICE!

The value for zero point adjustment is set ex works. After replacing the printhead, only service personnel are allowed to set this value anew.

The printer must be in Offline mode.

Press and hold the keys  +  (> 3 s) to access the service functions.


Press the key  until the menu item *ZP Y-Adjust* is displayed.

Indication of value in 1/100 mm.

After replacing the printhead - the print cannot be continued at the same position on the label, the difference can be corrected in printing direction.

While holding down the key  press the key  at the same time to increase the value.

While holding down the key  press the key  at the same time to increase the value.

Press the key  to confirm the selection.

Zero point adjustment in X direction




NOTICE!

The value for zero point adjustment is set ex works. After replacing the printhead, only service personnel are allowed to set this value anew.

The printer must be in Offline mode.

Press and hold the keys  +  (> 3 s) to access the service functions.


Press the key  as long as the menu item *ZP X-Adjust* is reached.

Indication of the value in 1/100 mm.

After replacing the printhead - the print cannot be continued at the same position on the label, the difference can be corrected across the printing direction.

While holding down the key  press the key  at the same time to increase the value.

While holding down the key  press the key  at the same time to increase the value.

Press the key  to confirm the selection.

5.4 Replace the Pressure Roller




Figure 7

Remove the pressure roller

1. Remove the left printer cover.
Loosen two screws at the lower left printer edge and three screws at the chassis upper edge.
2. Remove the protective conductor at the inside of printer cover.
3. Loosen the screw (D) and remove the tear off edge (if mounted) before the pressure roller (E).
4. Turn the red lever (A) counter clockwise to lift up the printhead.
5. Open the clutch (H) between motor (G) and pressure roller (E) by loosening the headless pin (I).
6. Remove the screw (B) at the outside of aluminum bearing.
7. Remove the bearing plate (C).
8. Pull the pressure roller (E) outwards. Hold the drive pulley (F).

Install the pressure roller

1. Mount the new pressure roller (E) through the drillings and the drive pulley (F).
2. When re-installing, pay attention to correct fit of the clutch (H).
3. Tighten the bearing plate (C) with the screw (B).
4. Close the clutch (H) by means of the headless pin (I).
The roller must be installed precisely.
5. Connect the protective conductor to the inside of cover.
6. Mount again the printer cover.

5.5 Replace the Label Photocell



NOTICE!

Soiling of the label photocell can also cause malfunctions. Before replacing the label photocell, check whether it is soiled and clean it if necessary (see chapter 4.5, on page 17).




Figure 8

Remove label photocell

1. Remove media from the printer.
2. Remove the left printer cover.
3. Loosen the plug connection of label photocell at the CPU.
4. Loosen both screws (A) and remove the label photocell (B).

Install the label photocell

1. Fix the label photocell (B) with both screws (A) at the main plate.
2. Guide the photocell cable through the slot hole (C).
3. Re-install the plug connection of the photocell with the CPU.
4. Install the left printer cover.
5. Adjust the label photocell.

5.6 Replace the CPU PCB




Figure 9

Remove the CPU PCB

1. Unplug the printer from the electrical outlet.
2. Detach all interface cables from the back of the printer.
3. Screw off the left printer cover.
4. Unplug all side plug connections from the CPU PCB.
5. Remove the two screw bolts (B) and four fixing bolts (A) from the CPU PCB.
6. Carefully remove the CPU PCB.

Install the CPU PCB

1. Place the CPU PCB into the printer.
2. Secure the PCB with two screw bolts (B) and four fixing screws (A).
3. Insert all plug connections on the PCB.
4. Restore all interface connections on the back of the printer.
5. Connect the power cable at the rear of the printer.
6. Update the firmware if necessary.
7. Adjust the label photocell.

5.7 Replace the Power Supply




Figure 10

Remove the power supply

1. Unplug the printer from the electrical outlet.
2. Unplug all cable connections from power supply (C).
3. Remove the CPU PCB (see chapter 5.6, on page 25).
4. Hold the power supply firmly and unscrew the two screws (A) at the printer.
5. Remove the power supply unit.

Install the power supply



NOTICE!

Pay attention to the correct position of voltage selector switch in the power supply unit.

1. Insert the new power supply (B) and secure it with screws (A) at the chassis.
2. Connect all cable connections at the power supply (B). Pay attention to polarity!
3. Install the CPU PCB (see chapter 5.6, on page 25).
4. Install again the label supports at the rewinding unit.

5.8 Replace the Battery



DANGER!

Danger of explosion due to improper replacement of the battery!

⇒ Use non-conductive tools.

⇒ Pay attention to polarity.




Figure 11

1. Lift up the fixing bracket by means of a non-metallic device (e.g. plastic ruler).
2. Remove the battery.
3. Insert a new battery (CR 2032) into the support (A) and pay attention to position of polarity.

6 Adjustments, Settings and Alignments



DANGER!

Risk of death via electric shock!

- ⇒ Before opening the housing cover, disconnect the label printer from the mains supply and wait for a moment until the power supply unit has discharged.

6.1 Adjust the Print Mechanism

Major adjustment of the printing mechanism beyond format-based settings is only required if the printhead assembly has been removed or parts in this area have been replaced. Excluded from this is the replacement of the printhead, after which readjustment is generally not required.

The following print quality imperfections may indicate maladjustment of the printing mechanism:

- Print image too light
- Print image is spotty
- Print image lighter on one side
- Horizontal lines not parallel to the horizontal label edges
- Clear lateral drift of the transfer ribbon



NOTICE!

Print image errors can also arise from wrinkling of the transfer ribbon. This is why the transfer ribbon feed path and the head locking system should be checked before making adjustments to the printing mechanism (see '*operating manual*').

Adjustment of the printing mechanism encompasses the following procedures in the order specified:

1. Adjust the position of printhead (see chapter 6.2, on page 30).
2. Adjust the head contact pressure (see page 31).
3. Adjust the transfer ribbon feed path (see chapter 6.3, on page 32).

6.2 Adjust the Printhead

Complete the following printhead settings to achieve the best possible print image:

- ⇒ Align the heating line with the highest point of the pressure roller. Density of the print image is the greatest at this point.
- ⇒ Set the parallelism of horizontal lines with the edge of the label.



CAUTION!

The printhead assembly can be damaged.

Attempting to adjust the printhead when the fixing screw (E) is tight can lead to defects at the printhead assembly.

- ⇒ Always loosen the fixing screw (E) before adjusting the printhead.



NOTICE!

Open and close the printhead locking device after each step of the adjustment.




Figure 12

Parallelism

An important characteristic for a high quality print is the parallelism of the focal line of the thermal printhead to the pressure roll. Because of the fact that the position of focal line of the printhead depends on fluctuations caused by production, it is necessary to adjust the parallelism.

1. Loosen the fixing screw (E) approx. ¼ rotations.
2. Adjust the parallelism with the adjusting screws (C+F)
Clockwise = printhead moves forwards
Counter clockwise = printhead moves backwards
3. Adjust the parallelism as long as the printing result comes up to your full expectation.
4. Tighten again the fixing screws (E).
5. Start a print order with approx. 10 labels and control the correct passage of transfer ribbon.

Pressure

Increasing the head contact pressure leads to an improvement of the print image density on the corresponding side and to a shifting of the ribbon feed path in the corresponding direction.

**CAUTION!**

Damage of printhead by unequal use!

⇒ Only change the factory settings in exceptional cases.

The selection of the smallest value can optimise the life cycle of printhead.

1. Turn the pressure pieces (A+B) to change the pressure of printhead.
2. Turning the pressure pieces
in clockwise direction increases the pressure
anticlockwise reduces the pressure.
3. Tighten again the pressure lever clockwise to lock the printhead.

Print position

Check the position of printout and if necessary adjust the print position (see chapter 5.3).

6.3 Adjust the Transfer Ribbon Feed Path

Adjust the transfer ribbon feed path by changing the head contact pressure. Increasing the head contact pressure with the screws (A) and (B) shifts the ribbon feed path in the corresponding direction. Possibly arising formation of wrinkles can be eliminated by bowing the printhead.




DANGER!

The printhead assembly can be damaged when bowing the printhead.

Turning the adjustment screw (D) too hard can cause damage to the printhead assembly.

- ⇒ As soon as a clear resistance is perceived when turning the adjustment screw (D), only continue turning the screw in very small increments, but no more than one eighth of a turn.
- ⇒ Only turn the adjustment screw (D) as far as is absolutely necessary.



1. Check the transfer ribbon feed path.
The wound-up ribbon should be the same distance from the disk of the winder as the supply roller is from the disk of the rewinder.
2. If the ribbon runs inward or outward, turn the corresponding screw (C) or (F) clockwise in small increments.
3. Wait until the ribbon feed path has stabilized after each step of the adjustment.
4. Check the ribbon feed path for wrinkles.
5. If the wrinkles cannot be remedied (e.g. wrinkles in the centre), turn the adjustment screw (D) clockwise with extreme care (see warnings) using a hexagonal wrench (1.5 mm) and observe the ribbon feed path. When the adjustment screw (D) is tightened, the printhead is bent downward slightly in the centre. A slight lightening at the edge areas of the print image could occur here.

Figure 13

6.4 Oil and Lubricate



NOTICE!

Make sure when oiling and greasing that no lubricants deposit on photocells, electronic components, circuit boards, printhead and rolls.




Figure 14

In case that dust or other dirt is deposit you have to clean the lubrication at first with alcohol.

Apply rather in regular intervals (once or twice a year) a bit of lubricant, as only rarely too much. Otherwise the surplus of lubricant could settle on neighbouring components and disturb the functions.

In case those components should have run it because of lack of lubricant, replace these as soon as possible so the functions of the components and the printer remain.

Install again all components which you have dismantled for the lubrication in the correct position.

Take care e.g. tensions of belt, springs etc.

7 Retrofit with Options



DANGER!

Risk of death via electric shock!

⇒ Before opening the housing cover, disconnect the label printer from the mains supply and wait for a moment until the power supply unit has discharged.

7.1 I/O Plate




Figure 15

1. Remove the left printer cover.
Loosen two screws at the lower left printer edge and three screws at the chassis upper edge.
2. Remove the protective conductor at the inside of the printer cover.
3. Remove the cover at the interface disruption from the chassis rear.
4. Fix the I/O plate (B) with the fixing screws (A) at the disruption.
5. Insert the connecting cables for inputs/outputs corresponding to the wiring plan (see chapter 9, on page 49) into the appropriate plug-in positions of the I/O plate and CPU PCB.
6. Connect the protective conductor to the inside of printer cover.
7. Mount again the printer cover.

7.2 Dispenser Unit




Figure 16

Dispenser unit without photocell

1. Remove the front panel and tear off edge (if mounted) at the front of printer.
2. Press the red locking piece (B) to open the dispenser roller.
3. Place the dispenser unit (A) in front of the pressure roller. Guide downwards the photocell cable between chassis and left support plate of the dispenser (only for dispenser unit with photocell).
4. Fix the dispenser unit with screws (C) at the aluminum profile underneath the pressure roller.
5. Engage again the dispensing whip.

Dispenser unit with photocell

1. Remove left printer cover. Loosen two screws at the lower left printer edge and three screws at the chassis upper edge.
2. Remove the protective conductor at the inside of the printer cover.
3. Guide the plug of the photocell cable through the slot hole in the main plate.
4. Insert the photocell cable corresponding to the wiring plan (see chapter 9, on page 49) into the appropriate plug-in positions of the dispenser photocell.
5. Connect the protective conductor to the inside of printer cover.
6. Mount again the printer cover.

7.3 Cutting Unit



DANGER!

Risk of injury, particularly during maintenance, the cutter blades are sharp!

- ⇒ Switch off before attaching the cutter!
- ⇒ The cutter may only be used when it is mounted on the printer!
- ⇒ Do not try to cut any materials which exceed the maximum width or thickness specifications.
- ⇒ Do NOT touch the area of the moving blades!




Figure 17

1. Remove the front panel and tear off edge (if mounted) and the knurled screw (L) at the front of printer.
2. Remove left printer cover.
Loosen two screws at the lower left printer edge and three screws at the chassis upper edge.
3. Remove the protective conductor at the inside of the printer cover.

4. Mount the enclosed motor cover (E) with discs (O) and screws (P) at the printer bottom (A).
5. Mount the two knurled screws (L) and the two lock nuts (F) at the flat rod (G).
6. Mount the flat rod (G) with screws (H) to the printer front.
7. Hang out at spring pin (I) the leg spring (J) of cutting unit (B).
8. Guide the plug of the cutter cable through the slot hole in the main plate.
9. Fix the cutting unit (N) with the enclosed screw at the aluminum profile.
10. Engage the leg spring (J) at spring pin (I) of cutting unit (N).
11. Fix the cutter front plate (M) of cutting unit (N) with knurled screws (L) at the flat rod (G) and on the side with screw (K).
12. Mount the label guiding (C) on the reversing shaft(B).
13. Mount the motor plate (Q) with the washers (R) and screws (S) at the bottom of printer.
14. Insert the cutter and connection cable corresponding to the wiring plan (see chapter 9, on page 49) into the appropriate plug-in positions of the PCB.
15. Connect the protective conductor to the inside of printer cover.
16. Mount again the printer cover.

8 Error Correction

| Error message | Cause | Remedy |
|--------------------|---|---|
| 1 Line too high | Line rises up completely or partly over the upper edge of label. | Move line down (increase Y value). Check rotation and font. |
| 2 Line too low | Line rises up completely or partly over the bottom edge of label. | Move line up (reduce Y value). Check rotation and font. |
| 3 Character set | One res. several characters of the text is res. are not available in the selected font. | Change text. Change font. |
| 4 Unknown BC type | Selected code is not available. | Check code type. |
| 5 Illegal rotation | Selected rotation is not available. | Check rotation. |
| 6 CV font | Selected font is not available. | Check font. |
| 7 Vector font | Selected font is not available. | Check font. |
| 8 Measuring label | While measuring no label was found. Set label length is too large. | Check label length and if labels are inserted correctly. Restart measuring anew. |
| 9 No label found | No label available. Soiled label photocell. Labels not inserted correctly. | Insert new label roll. Check if labels are inserted correctly. Clean the label photocell. |
| 10 No ribbon | During the print order the ribbon roll becomes empty (front printhead). Defect at the transfer ribbon photocell (front photocell). | Change transfer ribbon. Check transfer ribbon photocell (service functions). |
| 11 COM FRAMING | Stop bit error. | Check stop bits. Check baud rate. Check cable (printer and PC). |
| 12 COM PARITY | Parity error. | Check parity. Check baud rate. Check cable (printer and PC). |
| 13 COM OVERRUN | Loss of data at serial interface (RS-232). | Check baud rate. Check cable (printer and PC). |

| Error message | Cause | Remedy |
|--------------------------------|---|---|
| 14 Field number | Received line number is invalid. | Check sent data. Check connection PC - printer. |
| 15 Length mask | Invalid length of received mask statement. | Check sent data. Check connection PC - printer. |
| 16 Unknown mask | Transferred mask statement is invalid. | Check sent data. Check connection PC - printer. |
| 17 Missing ETB | No end of data found. | Check sent data. Check connection PC - printer. |
| 18 Invalid character | One res. several characters of the bar code is res. are not valid. | Change bar code data. Change font. |
| 19 Invalid statement | Unknown transferred data record. | Check sent data. Check connection PC - printer. |
| 20 Invalid check digit | For check digit control the entered res. received check digit is wrong. | Calculate check digit anew. Check code data. |
| 21 Invalid SC code | Selected SC factor is invalid for EAN res. UPC. | Check SC factor. |
| 22 Invalid number of digits | Entered digits for EAN res. UPC are invalid < 12; > 13. | Check number of digits. |
| 23 Type check digit | Selected check digit calculation is not available in the bar code. | Check calculation of check digit. Check bar code type. |
| 24 Invalid extension | Selected zoom factor is not available. | Check zoom factor. |
| 25 Offset sign | Entered sign is not available. | Check offset value. |
| 26 Offset value | Entered offset value is invalid. | Check offset value. |
| 27 Printhead temperature | Printhead temperature is too high. Defective printhead sensing device. | Reduce contrast. Change printhead. |
| 28 Cutter error | With cut an error occurred. Paper jam. | Check label run. Check cutter run. |
| 29 Invalid parameter | Entered data do not correspond to the characters allowed from the application identifier. | Check code data. |

| Error message | Cause | Remedy |
|------------------------------|--|---|
| 30 Application Identifier | Selected application identifier is not available in GS1-128. | Check code data. |
| 31 HIBC definition | Missing HIBC system sign. Missing primary code. | Check definition of HIBC code. |
| 32 System clock | Real Time Clock function is selected but the battery is empty. Defective RTC. | Change battery. Change RTC component. |
| 33 No CF interface | Interrupted connection CPU - CF card. Defective CF card interface. | Check connection CPU - CF card interface. Check CF card interface. |
| 34 No print memory | Not enough print memory available. | Check CF assembly on CPU. |
| 35 Printhead open | At start of a print order the printhead is open. | Close the printhead and start print order anew. |
| 36 BCD invalid format | BCD error Invalid format for the calculation of Euro variable. | Check entered format. |
| 37 BCD overflow | BCD error Invalid format for the calculation of Euro variable. | Check entered format. |
| 38 BCD division | BCD error Invalid format for the calculation of Euro variable. | Check entered format. |
| 39 FLASH ERROR | Flash component error. | Run a software update. Change CPU. |
| 40 Length command | Invalid length of the received command statement. | Check data sent. Check connection PC - printer. |
| 41 No drive | CF card not found / not correctly inserted. | Insert CF card correctly. |
| 42 Drive error | Impossible to read CF card (faulty). | Check CF card, if necessary change it. |
| 43 Unformatted | CF Card not formatted. | Format CF card. |
| 44 Delete directory | Attempt to delete the actual directory. | Change directory. |
| 45 Invalid path | Too long indication of path. | Indicate a shorter path. |

| Error message | Cause | Remedy |
|--------------------------|---|---|
| 46 Drive write-protected | Memory card is write-protected. | Deactivate write protection. |
| 47 Directory not file | Attempt to indicate a directory as file name. | Correct your entry. |
| 48 File already open | Attempt to change a file during an access is active. | Select another file. |
| 49 No file/directory | File does not exist on CF card. | Check file name. |
| 50 Invalid file name | File name contains invalid characters. | Correct entry of name, remove special characters. |
| 51 Internal file error | Internal file system error. | Please contact your distributor. |
| 52 Root full | The max. number (64) of main directory entries is reached. | Delete at least one main directory entry and create subdirectories. |
| 53 Drive full | Maximum CF capacity is reached. | Use new CF Card, delete no longer required files. |
| 54 File/directory exists | The selected file/directory already exists. | Check name, select a different name. |
| 55 File too large | During copying procedure not enough memory space onto target drive available. | Use a larger target card. |
| 56 No update file | Errors in update file of firmware. | Start update file anew. |
| 57 Invalid graphic file | The selected file does not contain graphic data. | Check file name. |
| 58 Directory not empty | Attempt to delete a not empty directory. | Delete all files and sub-directories in the desired directory. |
| 59 No CF interface | No CF card drive found. | Check connection of CF card drive. Contact your distributor |
| 60 No media | No CF card is inserted. | Insert CF card in the slot. |
| 61 Webserver error | Error at start of web server. | Please contact your distributor. |
| 62 Wrong PH FPGA | The direct print module is equipped with the wrong FPGA. | Please contact your distributor. |
| 63 End position | The label length is too long. The number of labels per cycle is too much. | Check label length res. the number of labels per cycle. |

| Error message | Cause | Remedy |
|---------------------------|--|---|
| 64 Zero point | Defective photocell. | Change photocell. |
| 65 Compressed air | Pressure air is not connected. | Check pressure air. |
| 66 External release | External print release signal is missing. | Check input signal. |
| 67 Column too wide | Wrong definition of column width res. number of columns. | Reduce the column width res. correct the number of columns. |
| 68 Scanner | The connected bar code scanner signals a device error. | Check the connection scanner/printer. Check scanner (dirty). |
| 69 Scanner NoRead | Bad print quality. Printhead completely soiled or defective. Print speed too high. | Increase contrast. Clean printhead or replace (if necessary). Reduce print speed. |
| 70 Scanner data | Scanned data does not correspond to the data which is to print. | Replace printhead. |
| 71 Invalid page | As page number either 0 or a number > 9 is selected. | Select a number between 1 and 9. |
| 72 Page selection | A page which is not available is selected. | Check the defined pages. |
| 73 Undefined page | The page is not defined. | Check the print definition. |
| 74 Format user guiding | Wrong format for customized entry. | Check the format string. |
| 75 Format date/time | Wrong format for date/time. | Check the format string. |
| 76 Hotstart CF | No CF card found. | If option hotstart was activated, a CF card must be inserted. Switch off the printer before inserting the memory card. |
| 77 Flip/Rotate | Selection of print of several columns and also mirror/rotate. | It is only possible to select one of both functions. |
| 78 System file | Loading of temporary hotstart files. | Not possible. |
| 79 Shift variable | Faulty definition of shift times (overlapping times). | Check definition of shift times. |
| 80 GS1 Databar | General GS1 Databar error. | Check definition and parameter of GS1 Databar code. |
| 81 IGP error | Protocol error IGP. | Check sent data. |

| Error message | Cause | Remedy |
|-------------------------|--|--|
| 82 Time generation | Printing creation was still active at print start. | Reduce print speed. Use printers' output signal for synchronization. Use bitmap fonts to reduce generating time. |
| 83 Transport protection | Both DPM position sensors (start/end) are active. | Displace zero point sensor Check sensors in service functions menu |
| 84 No font data | Font and web data is missing. | Run a software update. |
| 85 No layout ID | Layout ID definition is missing. | Define layout ID onto the label. |
| 86 Layout ID | Scanned data does not correspond to defined ID. | Wrong label loaded from CF card. |
| 87 RFID no label | RFID unit cannot recognize a label. | Displace RFID unit or use an offset. |
| 88 RFID verify | Error while checking programmed data. | Faulty RFID label. Check RFID definitions |
| 89 RFID timeout | Error at programming the RFID label. | Label positioning. Faulty label. |
| 90 RFID data | Faulty or incomplete definition of RFID data. | Check RFID data definitions. |
| 91 RFID tag type | Definition of label data does not correspond with the used label. | Check storage partitioning of used label type |
| 92 RFID lock | Error at programming the RFID label (locked fields). | Check RFID data definitions. Label was already programmed. |
| 93 RFID programming | Error at programming the RFID label. | Check RFID definitions. |
| 94 Scanner timeout | The scanner could not read the bar code within the set timeout time. | |
| | Defective printhead. Wrinkles in transfer ribbon. Scanner wrong positioned. Timeout time too short. | Check printhead. Check transfer ribbon. Position scanner correctly, corresponding to the set feeding. Select longer timeout time. |

| Error message | Cause | Remedy |
|---------------------------------|--|--|
| 95 Scanner layout difference | Scanner data does not correspond to bar code data. | Check adjustment of scanner. Check scanner settings / connection. |
| 96 COM break | Serial interface error. | Check settings for serial data transmission as well as cable (printer-PC). |
| 97 COM general | Serial interface error. | Check settings for serial data transmission as well as cable (printer-PC). |
| 98 No software printhead FPGA | No printhead-FPGA data available. | Please contact your responsible distributor. |
| 99 Load software printhead FPGA | Error when programming printhead-FPGA. | Please contact your responsible distributor. |
| 100 Upper position | Option applicator: Sensor signal up is missing. | Check input signals / compressed-air supply. |
| 101 Lower position | Option applicator: Sensor signal down is missing. | Check input signals / compressed-air supply. |
| 102 Vacuum plate empty | Option applicator: Sensor does not recognize a label at vacuum plate. | Check input signals / compressed-air supply. |
| 103 Start signal | Print order is active but device not ready to process it. | Check start signal. |
| 104 No print data | Print data outside the defined label. Selection of wrong module type (design software). | Check selected module type. Check selection of left/right version. |
| 105 Printhead | No original printhead is used. | Check the used printhead. Contact your distributor. |
| 106 Invalid Tag type | Wrong Tag type. Tag data do not match the Tag type in the printer. | Adapt data or use the correct Tag type. |
| 107 RFID inactive | RFID module is not activated. No RFID data can be processed. | Activate RFID module or remove RFID data from label data. |
| 108 GS1-128 invalid | Transferred GS1-128 bar code is invalid. | Verify bar code data (see GS1-128 bar code specification). |
| 109 EPC parameter | Error at EPC calculation. | Verify data (see EPC specification). |

| Error message | Cause | Remedy |
|----------------------|---|--|
| 110 Housing open | When starting the print order the housing cover is not closed. | Close the housing cover and start the print order anew. |
| 111 EAN.UCC code | Transferred EAN.UCC code is invalid. | Verify bar code data (see corresponding specification). |
| 112 Print carriage | Printing carriage does not move. | Check gear belt (possibly broken). |
| 113 Applicator error | Option applicator: Error while using applicator. | Check applicator. |
| 114 Left position | Option applicator: Left final position switch is not in correct position. | Check LEFT final position switch for correct function and position. Check function of pneumatics for cross traverse. |
| 115 Right position | Option applicator: Right final position switch is not in correct position. | Check RIGHT final position switch for correct function and position. Check function of pneumatics for cross traverse. |
| 116 Print position | Option applicator: The applicator is not in the print position when trying to print a label. | Check TOP and RIGHT final position switch for correct function and position. Check pneumatics for function |
| 117 XML parameter | The parameters in the XML file are not correct. | Please contact your responsible distributor. |
| 118 Invalid variable | Transferred variable is invalid with customized entry. | Select correct variable without customized entry and transfer it. |
| 119 No ribbon | During the print order the ribbon roll becomes empty (rear printhead). Defect at the transfer ribbon photocell (rear photocell). | Change transfer ribbon. Check transfer ribbon photocell (service functions). |
| 120 Wrong directory | Invalid target directory when copying. | Target directory must not be within the source directory. Check target directory. |
| 121 No label PH2 | No label found at the rear printhead (DuoPrint). Soiled label photocell. Labels not inserted correctly. | Insert new label roll. Clean the label photocell. Check if labels are inserted correctly. |
| 122 IP occupied | The IP address was already assigned. | Assign a new IP address. |

| Error message | Cause | Remedy |
|-------------------------|--|---|
| 123 Print asynchronous | <p>The label photocell does not work in the order as it is expected according to print data.</p> <p>The settings of the photocell are not correct.</p> <p>Settings of label size and gap size are not correct.</p> <p>No label found at the rear printhead.</p> <p>Soiled label photocell.</p> <p>Labels not inserted correctly.</p> | <p>Check label size and gap size.</p> <p>Check label photocell settings.</p> <p>Check correct loading of label material.</p> <p>Insert new label roll.</p> <p>Clean the label photocell.</p> <p>Check if labels are inserted correctly.</p> |
| 124 Speed too low | The print speed is too slow. | Increase the speed of customers' machine. |
| 125 DMA buffer | Communication problem HMI. | Restart the printer. |
| 126 UID conflict | Configuration RFID programming faulty. | Run RFID initialising. |
| 127 Module not found | RFID module not available. | <p>Check the RFID module connection.</p> <p>Please contact your responsible distributor.</p> |
| 128 No release signal | No print release by higher-level control (customer machine). | Activate release signal at the higher-level control. |
| 129 Wrong firmware | Firmware does not match the used printer type. | <p>Use firmware that fits to the printer type.</p> <p>Please contact your responsible distributor.</p> |
| 130 Language missing | Language file for the set printer language is not available. | Please contact your responsible distributor. |
| 131 Wrong material | Label material does not fit to printing data. | User label material with suitable label and/or gap length. |
| 132 Invalid mark-up tag | Invalid mark-up formatting characters in text. | Correct the formatting characters in the text. |
| 133 Script not found | LUA script file not found. | Check the file name. |

| Error message | Cause | Remedy |
|-----------------------------|--|--|
| 134 Script failure | LUA script is incorrect. | Check the script. |
| 135 Script user error | Error in LUA script user input. | Correct the input value. |
| 136 No reprint available | No label data for reprinting available. | Send new label data to the printer. |
| 137 Printhead short circuit | Electrical short at the printhead. | Check the used printhead. Please contact your distributor. |
| 138 Too less ribbon | Transfer ribbon ends. | Change transfer ribbon. |
| 139 Rewinder error | Label band is torn | Load a new label roll. Stick together the label band. |
| 140 Rewinder motor blocked | External rewinder motor is blocked. | Switch off the printing system and check mechanical resistance. Change the full label roll. |
| 141 Hardware error | A hardware component could not be found. | Please contact your responsible distributor. |
| 142 No print mechanics | No print mechanics connected. | Check connection (print mechanics – control unit) |

9 Control Inputs and Outputs

By means of a maximum of 16 control inputs and outputs which, in the following, are also referred to as ports, different functions of the printer system can be triggered and operating states can be displayed.

The ports are provided by means of a D-Sub bushing (26pin HD) at the rear panel of the printer system and are galvanically isolated from protective earth (PE) by means of an optocoupler semi-conductor route.

Each port can be configured as input and as output. This function however, is predefined in the printer software and cannot be changed by the user.

The following parameters can be changed and set by using the menu: debounce times and high or low active.

Printer, internal circuitry





Figure 18

**Configuration of
D-Sub socket****Figure 19****Cable identification**

| Number | Color |
|--------|--------------|
| 1 | white |
| 2 | brown |
| 3 | green |
| 4 | yellow |
| 5 | grey |
| 6 | pink |
| 7 | blue |
| 8 | red |
| 9 | black |
| 10 | violet |
| 11 | grey-pink |
| 12 | red-blue |
| 13 | white-green |
| 14 | brown-greed |
| 15 | white-yellow |
| 16 | yellow-brown |
| 17 | white-grey |
| 18 | grey-brown |
| 19 | white-pink |
| 20 | pink-brown |
| 21 | white-blue |
| 22 | brown-blue |
| 23 | white-red |
| 24 | brown-red |
| 25 | white-black |
| 26 | brown-black |

Port 1 to Port 16 = Assignment for I/O Profile *Std_Label*

| Identification | Pin | Description / Function |
|--------------------|---------------|--|
| Port 1 | 10 | Print start and cut (Input) |
| Port 2 | 1 | Reprint last printed label (Input) |
| Port 3 | 11 | Counter Reset (Input) |
| Port 4 | 2 | Option applicator only: Start application (Input) |
| Port 5 | 12 | Error reset (Input) |
| Port 6 | 3 | Cancel all print jobs (Input) |
| Port 7 | 13 | Label end sensor (Input) |
| Port 8 | 4 | External release signal (Input) |
| Port 9 | 15 | Error (Output) |
| Port 10 | 6 | Print order activ (Output) |
| Port 11 | 16 | Dispenser photocell: Label exists at dispenser photocell (Output) |
| Port 12 | 7 | Single print (Output) |
| Port 13 | 17 | Ready (Output) |
| Port 14 | 8 | Option applicator only: Ready for application (Output) |
| Port 15 | 18 | Option scanner only: Bar code not readable (Output) |
| Port 16 | 9 | Prior warning for transfer ribbon end (Output) |
| COM/VDC for Inputs | 19 | Common reference potential of all control inputs. 'COM/VDC for Inputs' is usually connected with the (-) terminal of the control voltage and the control inputs are switched to active (+). By means of the option '2nd LED', 'COM/VDC for Inputs' can optionally be connected with the (+) terminal of the control voltage. Then, the control inputs are switched to active (-). |
| VDC for Outputs | 20 | Common supply connection of all control outputs. 'VDC for Outputs' must be connected with the (+) terminal of the control voltage. Never leave 'VDC for Outputs' open even if no output is used. |
| COM for Outputs | 5,14 21,22 | Common reference potential of all control outputs. 'COM for Outputs' must be connected with the (-) terminal of the control voltage. Never leave 'COM for Outputs' open even if no output is used. |
| GND-PE | 23,24 | 'GND-PE' is the reference potential of the '+5 VDC EXT' and '+24 VDC EXT' voltages provided by the printer system. 'GND-PE' is printer internally connected with protective earth (PE). |

| Identification | Pin | Description / Function |
|-----------------|-----|--|
| + 5 VDC EXT | 25 | 5 Volt DC output for external use. Max. 0.5 A. This voltage is provided from direct print module and can be used e.g. as control voltage. Never apply any external voltage to this output. |
| + 24 VDC EXT | 26 | 24 Volt DC output for external use. Max. 0.5 A. This voltage is provided from direct print module and can be used e.g. as control voltage. Never apply any external voltage to this output. |

Port 1 to Port 16 = Assignment for I/O Profile *StdFileSelLabel*

| Identification | Pin | Description / Function |
|----------------|-----|---|
| Port 1 | 10 | Print start and cut (Input) |
| Port 2 | 1 | Error reset (Input) |
| Port 3 | 11 | Number of the file to load Bit 0 (Input) |
| Port 4 | 2 | Number of the file to load Bit 1 (Input) |
| Port 5 | 12 | Number of the file to load 2 (Input) |
| Port 6 | 3 | Number of the file to load 3 (Input) |
| Port 7 | 13 | Number of the file to load 4 (Input) |
| Port 8 | 4 | Number of the file to load 5 (Input) |
| Port 9 | 15 | Error (Output) |
| Port 10 | 6 | Print order active (Output) |
| Port 11 | 16 | Dispenser photocell: Label exists at dispenser photocell (Output) |
| Port 12 | 7 | Printing (Output) |
| Port 13 | 17 | Ready (Output) |
| Port 14 | 8 | No function |
| Port 15 | 18 | Option scanner only: Bar code not readable (Output) |
| Port 16 | 9 | Transfer ribbon prior warning (Output) |


Technical data

| | |
|---|--|
| Plug Connector | |
| Type | D-Sub connector High Density 26-pin. / connector |
| Manufacturer | W+P-Products |
| Reference number | 110-26-2-1-20 |
| Output Voltages (connected with GND-PE) | |
| + 24 V / 0.5 A* | Fuse: Polyswitch / 30 V / 1 A |
| + 5 V / 0.5 A* | Fuse: Polyswitch / 30 V / 1 A |
| Port 1 - 15 | |
| Input | |
| Voltage | 5 VDC ... 24 VDC |
| Impedance | $47\Omega + (100\text{nF} \parallel 10\text{ k}\Omega)$ |
| Output | |
| Voltage | 5 VDC ... 24 VDC |
| Impedance | $47\Omega + (100\text{nF} \parallel 10\text{ k}\Omega \parallel 47\Omega)$ |
| Current max. | High +15 mA Low -15 mA |
| Port 16 | |
| Input | |
| Voltage | 5 VDC ... 24 VDC |
| Impedance | $100\text{nF} \parallel 10\text{ k}\Omega$ |
| Output | |
| Voltage | 5 VDC ... 24 VDC |
| Impedance | $100\text{nF} \parallel 10\text{ k}\Omega$ |
| Current max. | High +500 mA (Darlington BCP56-16) Low - 500 mA (Darlington BCP56-16) |
| Optocoupler | |
| Output | TCMT4106, CTR 100 % - 300 %, Vishay or TLP281-4(GB), CTR 100 % - 600 %, Toshiba |
| Input | TCMT4106, CTR 100 % - 300 %, Vishay or TLP281-4(GB), CTR 100 % - 600 %, Toshiba |
| Input Option 2nd LED | TCMT4600, CTR 80 % - 300 %, Vishay or TLP280-4, CTR 33 % - 300 %, Toshiba |


* max. sum for all connected electric loads

Example 1

Device connection to a machine with S7-300 SPS.


**Figure 20****Example 2**

Device connection to a operating panel.

**Figure 21**

Example 3

Device connection version if 'Option: 2. LED'.

**Figure 22****Precautions**

When connecting a reed contact with a control input, the contact must have a switching capacity of min. 1 A in order to prevent the contact from sticking due to the inrush current. As an alternative, a suitable resistor can be connected in series.

If one of the printer's internal voltages '+5 VDC EXT' or '+24 VDC EXT' is used, an external fuse e.g. 0.5 AF, should be additionally installed to protect the printer electronics.

In the event of an inductive load, an antiparallel connected diode, for instance, must be used to discharge the induction energy.

In order to minimise the influence of leakage currents at control outputs, a resistor must, depending on what is connected, be installed in parallel with the load.

In order to avoid any damages to the printing system, the max. output currents must not be exceeded or outputs shorted.

10 Wiring Plan




Figure 23

10.1 CPU Component Placement Specification





Figure 24

Jumper plan

| | JP1 (Debug) | JP2 (write-protection) |
|-------------------------|-------------|------------------------|
| Boot sector Programming | closed | closed |
| Delivery | closed | open |

11 Environmentally-Friendly Disposal



Manufacturers of B2B equipment are obliged to take back and dispose of old equipment that was manufactured after 13 August 2005. As a principle, this old equipment may not be delivered to communal collecting points. It may only be organised, used and disposed of by the manufacturer. Valentin products accordingly labelled can therefore be returned to Carl Valentin GmbH.

This way, you can be sure your old equipment will be disposed of correctly.

Carl Valentin GmbH thereby fulfils all obligations regarding timely disposal of old equipment and facilitates the smooth reselling of these products. Please understand that we can only take back equipment that is sent free of carriage charges.

The electronics board of the printing system is equipped with a battery. This must only be discarded in battery collection containers or by public waste management authorities.

Further information on the WEEE directive is available on our website www.carl-valentin.de.

12 Index

A

| | |
|--|----|
| adjustments, settings, alignments | |
| head contact pressure (printhead)..... | 31 |
| oil and lubricate..... | 33 |
| print mechanism | 29 |
| printhead..... | 30 |
| transfer ribbon feed path..... | 32 |

B

| | |
|-------------------------|----|
| battery, replacing..... | 27 |
|-------------------------|----|

C

| | |
|---|------------------------|
| cleaning | |
| cleaning schedule | 13 |
| label photocell | 17 |
| pressure roller | 15 |
| printhead..... | 16 |
| component plan CPU | 58 |
| component replacing | |
| battery | 27 |
| CPU PCB..... | 25 |
| label photocell..... | 24 |
| power supply..... | 26 |
| pressure roller | 23 |
| printhead..... | 20, 21 |
| tool list..... | 19 |
| connector pin assignment, printer rear..... | 11 |
| control inputs/control outputs | 49, 50, 51, 52, 54, 55 |
| CPU | |
| component plan | 58 |
| CPU PCB, replacing | 25 |
| jumper plan | 58 |
| cutting unit, retrofit..... | 37, 38 |

D

| | |
|-------------------------------|----|
| dispenser unit, retrofit..... | 36 |
|-------------------------------|----|

E

| | |
|---|--|
| Electricity, safety handling..... | 9 |
| environmentally-friendly disposal | 59 |
| error messages/error corrections | 39, 40, 41, 42, 43, 44, 45, 46, 47, 48 |

I

| | |
|--------------------------|----|
| I/O plate, retrofit..... | 35 |
|--------------------------|----|

J

| | |
|-----------------------|----|
| jumper plan CPU | 58 |
|-----------------------|----|

L

| | |
|-----------------|----|
| label photocell | |
| cleaning..... | 17 |
| replacing | 24 |

M

| | |
|--------------------------------------|----|
| maintenance/cleaning | |
| ribbon drawing roller, cleaning..... | 14 |

N

| | |
|----------------|---|
| notes | |
| document | 5 |
| user | 5 |
| warnings | 5 |

O

| | |
|-------------------------|----|
| oil and lubricate | 33 |
|-------------------------|----|

P

| | |
|---------------------------------|--------|
| power supply, replacing..... | 26 |
| pressure roller | |
| cleaning..... | 15 |
| replacing | 23 |
| print mechanism, adjusting..... | 29 |
| print position, adjusting..... | 22 |
| printhead | |
| adjusting | 30 |
| cleaning..... | 16 |
| position, adjusting | 31 |
| replacing | 20, 21 |

R

| | |
|----------------------|--------|
| retrofit options | |
| cutting unit | 37, 38 |
| dispenser unit | 36 |
| I/O plate | 35 |

S

| | |
|---|---|
| safety handling when working with electricity | 9 |
| safety instructions | |
| clothing..... | 7 |
| protective clothing..... | 8 |
| protective equipment | 8 |
| workplace..... | 7 |

T

| | |
|---|----|
| tool list | 19 |
| transfer ribbon feed path, adjusting..... | 32 |

W

| | |
|-------------------|----|
| warnings | 5 |
| wiring plan | 57 |



Carl Valentin GmbH
Neckarstraße 78 – 86 u. 94
78056 Villingen-Schwenningen
Phone +49 7720 9712-0
info@carl-valentin.de
www.carl-valentin.de

